


IS45 Labeling

Step 1 : Detach the IS45 cover by a screw driver



Step 2 : Attach the labels on the buttons inside of cover , **The size of label : 12x12mm**



Step 3 : Reinstall the cover

